



ALLIANT ENERGY IP&L/WP&L TELEPHONE NUMBERS

Electric Service: 1-800-862-6222 or 1-800-ALLIANT
Outage Reporting: 1-877-740-5050 or 1-800-ALLIANT

PRE-EXCAVATION TELEPHONE NUMBERS

Iowa – Iowa One Call: 1-800-292-8989
Minnesota –Gopher State One Call: 1-800-252-1166
Wisconsin – Diggers Hotline: 1- 800-242-8511

ALLIANT ENERGY WEB SITE

Key in Web Site
www.alliantenergy.com/servicemanuals





TABLE OF CONTENTS

DIGGERS HOTLINE

Telephone Numbers - Alliant Energy – Web Site Information & Cable Location

CHAPTER 1 – GENERAL INFORMATION PAGE

100.	General	1-1
101.	Purpose.....	1-1
102.	Scope.....	1-1
103.	Word Application	1-1
104.	Continuity of Service.....	1-2
105.	Point of Service	1-2
106.	Codes And Rules	1-2
107.	Application For Service.....	1-2
108.	Service Voltages And Maximum Amperage (600 V. or Less).....	1-4
109.	Number of Services	1-4
110.	Short Circuit Duty Requirements	1-8
111.	Inspections and Maintenance	1-10
112.	Service Connections.....	1-10
113.	Identification of Conductors	1-10
114.	Capacity	1-10
115.	Addition To Existing (Rewire)	1-11
116.	Company Equipment On Customer Premises	1-11
117.	Sequence of Disconnecting Service And Meter	1-12
118.	Customer Installation.....	1-12
119.	Communication Tower Installation.....	1-13

CHAPTER 2 – TEMPORARY SERVICE

200.	General	2-1
201.	Large Capacity, Three Phase, and Primary Temporary Services	2-1
202.	Overhead Temporary Service, - Single Phase, 3-Wire, 120/240 Volt, 200 Amp Max. (For Construction Sites)	2-2
203.	Underground Temporary/Permanent Service - Single Phase, 3-Wire, 120/240 Volt, 200 Amp Max. (For Construction Sites) Preferred Construction	2-4
204.	Underground Temporary Service - Single Phase, 3-Wire, 120/240 Volt, 200 Amp Max. (For Construction Sites)	2-6
205.	Underground Temporary Service For Construction Sites – Single Phase 120/240 Volt 200 Amp Max.....	2-8



CHAPTER 3 – OVERHEAD SERVICE.....PAGE

301. Attachment of Service Drops 3-1

302. Service Mast Construction..... 3-1

303. Service Mast Installation of Flat or Low Roofed Buildings
Up to 1200 Amps – 480 Volts Maximum..... 3-3

304. Service Attachment to Brick or Masonry Walls and Metal
Buildings Up To 1200 Amps – 480 Volts Maximum 3-4

305. Service Riser Requirements 3-5

306. Wall or Through – The Roof Installation..... 3-6

307. Pole Mounted Service Entrance Up to 300 Amp-240 Volts
Maximum – Optional Construction Where No Building is
Available..... 3-8

CHAPTER 4 – UNDERGROUND SERVICE

400. General 4-1

401. Sizing Underground Facilities 4-1

402. Location of Alliant Energy Secondary Voltage Cables 4-2

403. Underground Service Installations 4-2

404. Outdoor Meter Socket, Single-Phase & Three-Phase,
300 Amps Max., 240 Volts Max. 4-4

405. Wall Mounted Pedestal Service – Single or Duplex – Single or
Three Phase – 300 Amps Max. - 240 Volts Max. 4-6

406. Free Standing Pedestal Service Entrance – Single Phase
& Three Phase – 300 Amps Max. 240 Volts Max..... 4-8

407. Rigid Conduit..... 4-10

408. Pad Specifications for Three-Phase Pad-Mount
Transformer 75-2500 KVA..... 4-12

409. Pad Layout for Three-Phase Pad-Mount Transformers
75-2500 KVA..... 4-14

410. Single Phase Box Pad..... 4-15

411. Transformer Pad Foundation Wall..... 4-16

CHAPTER 5 – GROUNDING

500. General 5-1

501. Grounding Electrode System..... 5-1

502. Grounding Service Entrance and Metering Equipment 5-2

503. Bonding 5-6



CHAPTER 6 – METERING..... PAGE

600. Metering Facilities..... 6-1

601. Location of Meters 6-1

602. Metering Installations 6-2

603. Clearance Requirements For Metering Equipment 6-3

604. Identification of Meters 6-3

605. Meter Seals 6-4

606. Separation of Metered And Un-metered Conductors 6-4

607. Meter Socket Requirements 6-4

608. 120/240 Volt Single Phase – Overhead- Self Contained 6-5

609. 120/240 Volt Single Phase – Underground-Self Contained 6-6

610. 120/208 Volt Single Phase(Network)-Overhead – Self
Contained 6-6

611. Three Phase – 4-Wire – OH/UG – Self Contained 6-7

612. 277/480 Volt, Three-Phase, Up to 200 Amps – OH & UG-
Self Contained – Limited to 10,000 Amps Maximum
Available Fault Current..... 6-8

613. Self Contained Multiple Metering Group & Modular (2 or more meters) Up to
200 Amps Per Socket, 250 Volts Maximum 6-10

614. Meter Shield 6-14

615. Outdoor Free Standing (Field Built) Meter Structures 6-15

616. Instrument Transformer Installations 6-16

617. Metering Transformer Installation – Overhead Service –
on Building Only (Do Not Install on a Pole)..... 6-18

618. Wall Mounted Outdoor Metering Transformer Cabinet –
Overhead Service 6-20

619. Wall Mounted Outdoor Metering Transformer Cabinet –
Underground Service..... 6-22

620. Pad Mounted Outdoor Metering Instrument Transformer
Cabinet – Underground Service 6-24

621. Combined Instrument Transformer, Self-Contained –
Multiple Metering, 240 Volts and Below, Prebussed/Wire
Equipment 6-26

CHAPTER 7 – HUD MOBILE/MANUFACTURED HOMES

700. General 7-1

701. Definitions 7-2

702. Service Entrance Equipment for HUD Mobile/Manufactured Homes 7-2

703. HUD Mobile/Manufactured Home Courts 7-3

704. HUD Mobile/Manufactured Home Service Entrance Pedestal
100-200 Amp, Single-Phase, 3-Wire – 120/240 Volt –
Underground 7-4

705. Field Built Service Entrance for HUD Mobile/Manufactured Homes,
100-200 Amp – 3-Wire – 120/240 Volt – Overhead 7-6



CHAPTER 7 – HUD MOBILE/MANUFACTURED HOMES (Continued) PAGE

706. Field Built Service Entrance for HUD Mobile/Manufactured Homes,
100-200 Amp, 3-Wire – 120/240 Volts, Underground 7-8

707. Manufactured Home Service Pedestal, Mounted on the Frost
Wall, Permanent Foundation, Single-Phase, 100-200 Amp,
120/240 Volts 7-10

708. Manufactured Home Service Pedestal, Mounted on Full
Basement, Permanent Foundation, Single-Phase,
100 – 200 Amp, 120/240 Volts 7-12

CHAPTER 8 – FARM SERVICES

801. Scope 8-1

802. Farm Service Yard Pole or Structure 8-1

803. Overhead Service to a Farm Yard Pole-With Grade
Level Disconnect and Overcurrent Protection, 300 Amp
Max., & 240 Volt Max. 8.4

804. Overhead Service to a Field Built Structure, with Grade
Grade Level Disconnect and Overcurrent Protection,
300 Amp Max & 240 Volt Max. 8-6

805. Overhead Service to a Farm Yard Pole-With Pole
Top Transfer Switch 8-8

806. Overhead Service for Farm/ Irrigation Service, 100-800 Amp,
277/480 Volt, Three Phase 8-10

807. Underground Service from an Overhead Transformer
to a Farm on Field Built Structure, 300 Amps
Max., 240 Volts Max. 8-12

808. Underground Service to a Farm on Field Built Structure
with Overcurrent Protection, 301-1200 Amp, 480Volts Max. 8-14

CHAPTER 9 – SPECIAL SERVICES

900. General 9-1

901. Special Pole-Mount Service, 120/240 Volt, Single-Phase,
3-Wire, 200 Amp Max. (CATV, Telephone, or Municipal) 9-2

902. Underground Service, 120/240 Volt, Single-Phase, 3-Wire,
200 Amp Max (CATV, Telephone, or Municipal) 9-4

CHAPTER 10 – PRIMARY SERVICES

1000. General 10-1

1001. Overhead Primary Service 10-4

1002. Underground Primary Service 10-6

1003. Underground Primary Service With Overhead Metering 10-10

1004. Underground Primary Service to Metering Enclosure 10-12



CHAPTER 11 – CLEARANCES..... PAGE

1101. Minimum Clearances for Services 300 Volts and Below 11-1

1102. Min. Clearances for Service 300 Volts and Below over Pools..... 11-3

1103. Clearance for Services Over State and Federal Highways 11-4

1104. Service Conductor Clearance From Signs 11-4

1105. Service Mast Installation – Roof Clearances of Service Drop
Terminating on Support Mast 300 Volts or Less 11-5

1106. Clearance Envelope for Grain Bins Filled by Portable Augers,
Conveyors, and Elevators..... 11-6

1107. Special Horizontal Clearances for Overhead Cable Services
(0-480 Volts)..... 11-7

1108. Pad-Mount Transformers Locations..... 11-8

1109. Non-Combustible Building Walls..... 11-9

1110. Combustible Building Walls 11-11

1111. Barriers 11-12

1112. Fire Escapes 11-13

1113. Single Phase Padmounted Transformer - Protection..... 11-15

1114. Three Phase Padmounted Transformer Protection..... 11-16

CHAPTER 12 – OPTIONAL STAND-BY SYSTEMS

1201. Scope..... 12-1

1202. Safety 12-1

1203. Transfer System Requirements 12-1

1204. Transfer Switch Options 12-2

1205. Connection and Neutral Switching Requirements..... 12-3

1206. Stand By Generator Installation (Generator Supplies All of
Customer’s Load At Two different Locations) Single Phase
– 120/240 V. Up to 300 Amps..... 12-6

CHAPTER 13 – SERVICE IMPAIRING EQUIPEMENT

1301. Service Impairing Equipment..... 13-1

1302. Phase Balance Equipment 13-1

1303. Power Factor Correction..... 13-1

1304. ARC Welders..... 13-1

1305. Protection and Control..... 13-2

1306. Motor Specifications 13-2